


## Movement cal. 3603



### **Technical Specifications:**

Diameter: 36mm , Height 4,6mm, 18 Jewels  
Manual winding, small second-hand at „9“  
18000 vph  
Shock resistance balance,  
Power reserve 41 h

### **Manual**

1. The watch is wound up by turning the crown clockwise.
2. To set the time pull out the crown and adjust the time. After that press the crown in its initial position. *(Note for watches with screwed-in crown: first unscrew the crown counterclockwise, then adjust the time by rotating the hands clockwise, finally screw the crown back while slightly pressing it.)*

### **WARNING:**

Do not use any force to wind up the watch. The watch is completely wound-up when you feel slight resistance.

If you follow these instructions and use the watch carefully it will work trouble-free and keep high accuracy for a long time.